

Installation instructions for CognitiveTPG Printer Administrator on computers where Administrator was not previously installed

Before installing **CognitiveTPG Printer Administrator** check your *Add/Remove Programs* folder in the Control Panel on your desktop for the following Programs:



Java™ 6 Update11 or higher

or Java SE Runtime Environment (JRE) 6 Update 11 or higher

NOTE: Java SE Runtime Environment (JRE) 6 Update 11 is preferred because of its smaller file size; it is ~15MB vs. 94MB for Java™ 6 Update11.


1. If it is not installed go to <http://java.sun.com/javase/downloads/index.jsp> and scroll down the web page to find the latest Java SE 6 update. Download the JRE for the latest Java SE 6 version



Clicking the JRE Download button will open a screen with many file choices to download. Choose one of the files listed below if you are using a Windows Operating system (either 32-bit or 64-bit) use one of the following downloads:

Windows x86 Online	0.87 MB	jre-6u43-windows-i586-iftw.exe
Windows x86 Offline	16.24 MB	jre-6u43-windows-i586.exe

2. Check your *Add/Remove* Programs folder to make sure that Microsoft.NET Framework 2.0 is installed, if not, go to <http://www.microsoft.com/downloads/details.aspx?familyid=0856eacb-4362-4b0d-8edd-aab15c5e04f5&displaylang=en> and refer to Microsoft instructions for installation.



3. Install CognitiveTPG Printer Administrator using one of the links listed below: (if you don't know if you have a 32 or 64 bit Windows system follow this link: <http://windows.microsoft.com/en-US/windows7/find-out-32-or-64-bit>)

CognitiveTPG Printer Administrator (C) 32-Bit
<http://jadmin.cognitive.com/c-series/32/JAdmin.jnlp>

Or
CognitiveTPG Printer Administrator (C) 64-Bit
<http://jadmin.cognitive.com/c-series/64/JAdmin.jnlp>